

DMX CHART 8 BIT

CHANNEL	CHANNEL MODE
1	Dimmer
2	CCT setting

DMX CHANNEL	VALUE	PERCENT	FUNCTION
1	0 – 255	0 – 100	Dimming
2	0 – 255	0 – 100	CCT 2.700K to 6500K

DMX CHART 16 BIT

CHANNEL	CHANNEL MODE
1	Dimmer
2	Dimmer fine
3	CCT setting

DMX CHANNEL		VALUE	PERCENT	FUNCTION
HI	LO	0 – 65535	0 – 100	Dimming
1	2			
3		0 – 255	0 – 100	CCT 2.700K to 6500K